

# AQUAFIT USA CERAMIC TILE

As per your request, we are providing the following information and/ or procedures regarding the Better-Bench™ installation in glass block:

- Step 1: Begin the erection of the glass block wall.
- Step 2: Determine the best horizontal joint line that will align with the mounting holes of the Better-Bench™ and provides the closest finished bench height preference(usually between 16"-21").
- Step 3: Apply fresh glass block mortar at this level. While holding the Better-Bench™ just below its finished position, place fasteners with sleeves in mortar to align with Better-Bench™ mounting holes. Sleeve flange should be flush with face of glass block. **Note:** Prior to insertion of fasteners with sleeves, make sure that screw head is touching sleeve flange!
- Step 4: Finish glass block wall and then wait 24 hrs to complete bench installation.
- Step 5: Carefully remove fasteners from sleeves. Follow the Better-Bench™ installation instructions provided with the unit and then complete all tile operations. **Warning: Do not over tighten fasteners when remounting bench unit to glass block wall. Hand tight is sufficient. Over tightening may cause fastener sleeve to expand and damage glass block joint.**

**ENJOY YOUR NEW SHOWER!**